

Installation of Minolta Copiers on Win2000

Installation steps

1. Install "Print Services for Unix" by the following: Click on Start/Settings/Control Panel, choose Add/Remove Programs, click on "Add/Remove Windows Components"
2. A Windows Components window pops up. Double-click on "Other Network and File Print Services" and place a check beside "Print Services for Unix". Click on OK. Click on Next.
3. A window will pop up asking you to place the Win 2000 CD in the CDRom drive.
(or point to the i386 folder)
4. Click on Finish when installation is done.
5. Close all windows
6. Click on Start/Settings/Printers, choose "Add Printer". Click on Next
7. Click on radio button beside "Local Printer"
Remove or deselect the check beside "Automatically detect Plug and Play Printers"
8. Click on Next
9. Click on radio button beside "Create a new port:", click on the down arrow and choose "LPR Port", Click Next
10. Enter the printers IP address and printer queue (ie: print, hold, direct), click OK
11. The "Add Printer Wizard" window pops up. Click on "Have Disk" button.
12. Navigate to the location of the Win2000 printer driver with the Browse button. Click OK
13. Choose the printer driver. Click on Next
14. In box labeled "Printer Name", please type in a printer name of your choice
(IE. Minolta Di520)
15. Click on Next, Next
16. Click Next to print a test page
17. Click Finish
18. Now you need to change the printer settings in the properties of the printer.
19. Install printer driver on each workstation